



DEFENDER[®]

ROOF EDGE PROTECTION


OPEN ECONOMY SYSTEM



OPEN STANDARD SYSTEM



OPEN PLUS SYSTEM



INSTALLATION INSTRUCTIONS

UN-RESTRAINED OPEN SYSTEMS

A wall, minimum 150 mm high,
within 2 m of system.

TO EN 14122 PART 3

UPRIGHTS POSTS

MAX 2M BAY CENTRES


TO EN 13374 CLASS A

FIRST & LAST BAYS MAX 2 M

ALL OTHER BAYS BAYS MAX 2.4 M

Installation Instructions should be read
in conjunction with Defender Roof Edge
Protection Operation & Maintenance
Manual.


©2012 Access Technologies Limited.
All Rights Reserved.




DEFENDER®

ROOF EDGE PROTECTION


SEMI CLOSED ECONOMY



SEMI CLOSED STANDARD



SEMI CLOSED PLUS



INSTALLATION INSTRUCTIONS

UN-RESTRAINED SEMI CLOSED SYSTEMS

A wall, minimum 150 mm high,
within 2 m of system.

TO EN 14122 PART 3

UPRIGHTS POSTS

MAX 2M BAY CENTRES


TO EN 13374 CLASS A

FIRST & LAST BAYS MAX 2 M

ALL OTHER BAYS BAYS MAX 2.4 M

Installation Instructions should be read
in conjunction with Defender Roof Edge
Protection Operation & Maintenance
Manual.


©2012 Access Technologies Limited.
All Rights Reserved.




DEFENDER[®]

ROOF EDGE PROTECTION


FULLY CLOSED ECONOMY



FULLY CLOSED STANDARD



FULLY CLOSED PLUS



INSTALLATION INSTRUCTIONS

UN-RESTRAINED

FULLY CLOSED SYSTEMS

A wall, minimum 150 mm high,
within 2 m of system.

TO EN 14122 PART 3

UPRIGHTS POSTS


MAX 2M BAY CENTRES

TO EN 13374 CLASS A

FIRST & LAST BAYS MAX 2 M

ALL OTHER BAYS BAYS MAX 2.4 M


Installation Instructions should be read
in conjunction with Defender Roof Edge
Protection Operation & Maintenance
Manual.




DEFENDER®

ROOF EDGE PROTECTION


OPEN ECONOMY SYSTEM



OPEN STANDARD SYSTEM



OPEN PLUS SYSTEM



INSTALLATION INSTRUCTIONS

RESTRAINED OPEN SYSTEMS

Abutted to a wall minimum 150 mm high.

TO EN 13374 CLASS A
FIRST & LAST BAYS MAX 2 M
ALL OTHER BAYS BAYS MAX 2.8 M

Installation Instructions should be read
in conjunction with
Defender Roof Edge Protection Operation
& Maintenance Manual.

©2012 Access Technologies Limited.
All Rights Reserved.